# Electrical Spin Injection, Accumulation, and Detection in Lateral Ferromagnet/Semiconductor Devices

Scott Crooker, Madalina Furis, Darryl Smith Los Alamos National Laboratory


Xiaohua Lou, Paul Crowell School of Physics and Astronomy, University of Minnesota

Christoph Adelmann, Chris Palmstrøm Dept. of Chemical Engineering and Materials Science, Univ. of Minnesota

- ♦ Spin transport in ferromagnet/semiconductor devices
- $\diamond$  Injection  $\rightarrow$  Transport  $\rightarrow$  Detection<sup>\*</sup> in one device
- ♦ Electrical detection of spin accumulation


Supported by DARPA SPINS, ONR, NSF MRSEC 02-12032, and the LANL LDRD Program

# "Ritual viewgraph" showing a spin-FET



Datta and Das, Appl. Phys. Lett. 56, 665 (1990)

- Inject spins from a ferromagnetic source
- Transport in the channel (minimize relaxation)
- Detection at drain contact
- Transimpedance depends on relative magnetizations of source and drain




Datta and Das, Appl. Phys. Lett. 56, 665 (1990)

- Inject spins from a ferromagnetic source
- · Gentsplothenorientation of the spine acristing of the drain (relative
- Detection at drain contact
- Transimpedance should depend on precession angle Transimpedance depends on relative magnetizations of source and drain

This has not yet been successfully implemented (no Hanle effect)


### Hanle Effect for diffusive spin transport




- Application of a transverse field induces precession but also dephasing due to a distribution of transport times (diffusion)
- Spin-dependent signal should be suppressed in large fields
- This can usually be done in a geometry that leaves the magnetizations of the electrodes fixed
- Metallic F-N-F systems have passed this test: Johnson and Silsbee: Phys. Rev. Lett. 55, 1790 (1985) Jedema *et al.*, Nature 416, 713 (2002)

### Things that work Part I: Spin transport in GaAs

J. M. Kikkawa and D. D. Awschalom Nature **397**, 6715 (1999)




Doping:  $1-3 \times 10^{16} \text{ cm}^{-3}$ Spin drift lengths > 100 microns Diffusion constant ~ 10 cm<sup>2</sup>/s Spin lifetime: 100 nsec



S. A. Crooker and D. L. Smith Phys. Rev. Lett. **94**, 236601 (2005)


This imposes no practical limitations. 2D systems are more difficult.....

#### **Things that work Part II: Electrical spin injection**




Graded doping profile: A. T. Hanbicki et al., Appl. Phys. Lett. 82, 4092 (2003)

#### **Electrical spin injection: PDI,NRL, IMEC, IBM, Minnesota**



- But: EL polarization is used to detect the injected spins "at the source"
- This has limited the amount of physics done with these devices


### **Simple channel device + Kerr microscopy + Precession**




Hanle MOKE: J. Stephens et al., Phys. Rev. Lett. 93, 097602 (2004).


- Contact magnetization is unchanged by the applied field.
- Polar Kerr microscopy detects the *z*-component of the spin.


### Kerr image under bias and in a small transverse field




### **Reverse the bias current....**








### **Dependence of Hanle signal on the magnetization**




### **Summary of Principal Observations**




- Cloud of spins emitted from the source ( $I_D \sim 30$  microns)
- Polarization ~5% near the injection contact (not well-calibrated)
- Sign corresponds to injection of majority spins
- Sign reverses when the magnetization is reversed
- Spin accumulation is observed near the forward-biased drain contact; as observed under MnAs/GaAs barriers: Stephens *et al.*, PRL **93**, 097602 (2004)
- The sign of the accumulated polarization is the same as the injected polarization

### **Drift-Diffusion Model**

• Account for diffusion, drift, and relaxation:






D = diffusion constant  $v_d = \mu E =$  drift velocity  $\tau_s =$  spin lifetime

 $\Omega$  = Larmor frequency w = width of contact x = distance from edge of contact

# **Drift-Diffusion Model**

Integrate over time (steady-state solution) and spatial extent of source


$$S_{z}(x) = k \int_{x=0}^{x+w} \int_{0}^{\infty} \frac{S_{x0}}{\sqrt{4\pi Dt}} e^{-\frac{(x'-v_{d}t)^{2}}{4Dt} - \frac{t}{\tau_{s}}} \sin(\Omega t) dt dx'$$



D = diffusion constant  $v_d = \mu E =$  drift velocity  $\tau_s =$  spin lifetime


 $\Omega$  = Larmor frequency w = width of contact x = distance from edge of contact


#### Vary distance of probe beam from the source contact



- There are four parameters ( $\tau_s = 125 \text{ ns}$ ,  $D = 10 \text{ cm}^2/\text{s}$ ,  $v_D = 2.8 \times 10^4 \text{ cm/s}$ , and an amplitude S<sub>0</sub>), which are the same for all curves.
- Near-field regime (dominated by diffusion, which sets width of Hanle "envelope")
- Drift regime:  $l > \sqrt{D\tau_s}$ ; precession during time-of-flight (oscillations)


Far field: precession during time-of-flight





At  $x_0 = 65 \ \mu\text{m}$ ,  $B_{\text{peak}} = 1.35 \ \text{Gauss}$ ,  $T = \pi/2\Omega_L \sim 300 \ \text{ns}$ , or  $v_d \sim 2.8 \times 10^4 \ \text{cm/s}$ 


#### Vary distance of probe beam from the *drain* contact



- Near the drain: diffusion is "fighting" drift  $\rightarrow$  rapid attenuation with distance
- One needs a relatively transmissive barrier (so that electric fields are small) in order to see the spin accumulation in the channel region
- Can we say any more about this?


#### **Observation of precession due to strain:**

Y. Kato et al., Nature 47, 50 (2004)




• Effective magnetic field depends on magnitude and *direction* of k.


### Put the sample in a vise....



S. A. Crooker and D. L. Smith Phys. Rev. Lett. **94**, 236601 (2005)


> Stress along <110> directions: Strain tensor has only two (identical) off-diagonal elements. Effective field φ is always *orthogonal* to **k**.





 $B_{applied} = 0; v_d \sim 3 \times 10^4 \text{ cm/sec}$ 

#### A means to measure momentum of the spin-polarized electrons:



• At opposite ends of the channel, the Hanle curves shift in **opposite** directions with increasing strain. *The (diffusive) spin current at the drain is flowing against the charge current*.


# What is going on at the drain?

- The spin accumulation is due to reflection from the ferromagnetic drain contact, as observed in MnAs/GaAs by Stephens *et al.*
- The devices under study here have more transparent tunnel barriers. It is much easier for electrons to diffuse "backwards" against the drift current, which is why spin polarization can be observed in the channel.
- 3. This is (apparently) not filtering by the tunnel barrier, at least in the sense predicted by the *average* density of states, which gives the wrong sign. Energy-selective or *k*-selective spin filtering may be a possibility. See arguments of Ciuti, McGuire, and Sham.
- 4. The mechanism is relatively efficient. The spin polarization at the drain is of the same order of magnitude as at the source.

# **Electrical spin detection**\*

- The above data imply that the conductance of the minority spin channel at the drain should be *higher* than the conductance of the majority channel.
- Can we verify this explicitly?


Inject spins of a known sign optically and measure the conductance:




drain contact

Бe

#### Schottky tunnel barriers can serve as electrical spin detectors:




- Hanle effect observed; inverts
  when magnetization is reversed
- Signal only for flow into drain contact



• Conductance is higher for the minority channel, consistent with the sign of the spin accumulation.

# Summary

- 1. It is possible to study separately each "element" of a spin transport device: source, channel, and drain.
- 2. A definitive demonstration of a ferromagneticsemiconductor device that functions as both a source and detector of spin-polarized electrons (passes the "Hanle test").
- 3. This has given us a very good idea of what to look for in a "real" transport experiment, without the assistance of photons. We know that there is spin accumulation at the drain, even in the absence of a spin-polarized source.
- We know what to look for in the magnetic field dependence (also temperature dependence and doping dependence, which I have not discussed here).
- S. A. Crooker et al., Science **309**, 2191 (2005).




- Samples studied: 2 x 10^{16}/cm^3 \leqslant n \leqslant 3 x 10^{17}/cm^3
- Al control sample: replace Fe with Al


- Applied magnetic field is small, ~100 Oe
  ➢ Fe magnetization is fixed.
- Channel length >> spin drift and diffusion length

#### Graded doping structure:


A. T. Hanbicki et al., Appl. Phys. Lett. 82, 4092 (2003).




# **Source/Drain Asymmetry**




- Voltage peak and source/drain asymmetry observed on samples: 2 x 10^{16}/cm^3  $\leqslant$  n  $\leqslant$  1.5 x 10^{17}/cm^3
- No peak observed on the AI control sample
- Contact magnetization has remained fixed



# Drain voltage is polarization-dependent



Modeling: spin drift-diffusion model




$$S_{x}(B) = \int_{0}^{L_{eff}} dx_{1} \int_{0}^{L_{eff}} dx_{2} \int_{0}^{\infty} dt \frac{S_{0}}{\sqrt{4\pi Dt}} e^{-\frac{(x_{2}-x_{1}+v_{d}t)^{2}}{4Dt} - \frac{t}{\tau_{s}}} \cos(\frac{g\mu_{B}B}{\hbar}t)$$

• Time scales that play a role:  $\tau_s$ ,  $L_{eff}/v_d$ ,  $L_{eff}^2/D$  ,  $4D/v_d^2$ 

Modeling parameters: D = spin diffusion constant:  $v_d = \text{spin drift velocity:}$   $\tau_s = \text{spin relaxation time:}$   $L_{eff} = 15 \ \mu\text{m} < L_{Fe} = 40 \ \mu\text{m:}$  $S_0 = \text{spin generation rate:}$ 

determined from transport determined from transport determined from optical Hanle effect fixed parameter unknown, free parameter

# Detection of Spin Accumulation at the Drain



Electrical detection; curves are fits with the drift-diffusion model

Optical detection of spin injection from the source, modeled with the same parameters (except for the amplitude)

# Summary (Part II)

- The spin accumulation at the drain can be detected in a Hanle-style experiment.
- Consistency with optical measurements strongly supports the interpretation of the transport measurements.
- The signal is not sensitive to the sign of the polarization.
- The obvious next step is a non-local measurement (in progress)
- The source-drain measurement is more problematic. In this respect, the effect demonstrated here is a nuisance, and a non-local measurement appears to be essential.


X. Lou et al., cond-mat/0602096

# Hanle curves from Kerr imaging

 $n = 3.6 \times 10^{16}/cm^3$ 

Spin injection at the source

Spin accumulation at the drain



- These are used to establish that a polarization exists at both source and drain
- Samples are also characterized by the Hanle effect under optical pumping